

NO-A102 120


RESULTS OF THE CRC (COORDINATING RESEARCH COUNCIL)
COOPERATIVE TEST PROGR. (U) GEO-CENTERS INC NEWTON
CENTRE MA J M HALL ET AL. 21 MAY 87 NRL-MR-5905


1/1

UNCLASSIFIED

F/G 21/4

NL





MICROCOPY RESOLUTION TEST CHART

Naval Research Laboratory

Washington, DC 20375-6000

2



NRL Memorandum Report 5985

DTIC FILE COPY

Results of the Third CRC Cooperative Test Program on Hydroperoxide Potential of Jet Fuels

J. M. HALL* AND R. N. HAZLETT

*Navy Technology Center for Safety and Survivability
Chemistry Division*

**Geo-Centers, Inc.
Newton Centre, MA 02159*

AD-A182 128

May 21, 1987

DTIC
ELECTE
JUL 08 1987
S E D

A182128

REPORT DOCUMENTATION PAGE

1a. REPORT SECURITY CLASSIFICATION UNCLASSIFIED			1b. RESTRICTIVE MARKINGS	
2a. SECURITY CLASSIFICATION AUTHORITY			3. DISTRIBUTION/AVAILABILITY OF REPORT Approved for public release; distribution unlimited.	
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE			5. MONITORING ORGANIZATION REPORT NUMBER(S)	
4. PERFORMING ORGANIZATION REPORT NUMBER(S) NRL Memorandum Report 5985			7a. NAME OF MONITORING ORGANIZATION	
6a. NAME OF PERFORMING ORGANIZATION Naval Research Laboratory		6b. OFFICE SYMBOL (If applicable) Code 6180	7b. ADDRESS (City, State, and ZIP Code)	
6c. ADDRESS (City, State, and ZIP Code) Washington, DC 20375-5000			9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER	
8a. NAME OF FUNDING/SPONSORING ORGANIZATION Naval Air Propulsion Center		8b. OFFICE SYMBOL (If applicable)	10. SOURCE OF FUNDING NUMBERS	
8c. ADDRESS (City, State, and ZIP Code) P.O. Box 7176 Trenton, NJ 08628			PROGRAM ELEMENT NO. 63724N	PROJECT NO. 20838
			TASK NO. 251950	WORK UNIT ACCESSION NO. DN580-087
11. TITLE (Include Security Classification) Results of the Third CRC Cooperative Test Program on Hydroperoxide Potential of Jet Fuels				
12. PERSONAL AUTHOR(S) Hall,* J. M. and Hazlett, R. N.				
13a. TYPE OF REPORT Final		13b. TIME COVERED FROM 2/86 TO 1/87	14. DATE OF REPORT (Year, Month, Day) 1987 May 21	15. PAGE COUNT 47
16. SUPPLEMENTARY NOTATION *Geo-Centers, Inc., Newton Centre, MA 02159				
17. COSATI CODES			18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)	
FIELD	GROUP	SUB-GROUP	Jet fuels, Cooperative experiments, Peroxidation, tests	
19. ABSTRACT (Continue on reverse if necessary and identify by block number)				
<p>Eight laboratories conducted tests on nine fuels to evaluate an accelerated storage stability test procedure for measuring the hydroperoxide forming potential of jet fuels. Based on the cooperative work reported herein the 65°C accelerated test readily distinguishes between stable and unstable fuels in approximately 3 weeks stress time. Consequently it appears useful for screening jet fuels for their long-time oxidation stability. Thus this test is recommended as a Go-No-Go test and this is what was sought in these studies. On the other hand, the variability of results within and between laboratories would seem to preclude its use as a precise quantitative tool.</p> <p><i>Keywords:</i></p>				
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input checked="" type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT. <input type="checkbox"/> DTIC USERS			21. ABSTRACT SECURITY CLASSIFICATION UNCLASSIFIED	
22a. NAME OF RESPONSIBLE INDIVIDUAL R. N. Hazlett			22b. TELEPHONE (Include Area Code) (202) 767-3559	22c. OFFICE SYMBOL Code 6180

CONTENTS

INTRODUCTION.....	1
EXPERIMENTAL.....	2
RESULTS.....	3
Analytical Variability.....	3
Variability of Triplicate Fuel Samples (Bottles).....	4
Variation Between Laboratories.....	5
Control Sample.....	6
Effect of Sample Size.....	8
Evaluation of Go/No-Go Test Potential.....	8
CONCLUSIONS.....	9
REFERENCES.....	10

Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A-1	



FIGURES

Fig.		Page No.
1	Aver. Peroxide Number vs Stress Time - Fuel 1	28
2	Aver. Peroxide Number vs Stress Time - Fuel 2	29
3	Aver. Peroxide Number vs Stress Time - Fuel 3	30
4	Aver. Peroxide Number vs Stress Time - Fuel 4	31
5	Aver. Peroxide Number vs Stress Time - Fuel 5	32
6	Aver. Peroxide Number vs Stress Time - Fuel 6	33
7	Aver. Peroxide Number vs Stress Time - Fuel 7	34
8	Aver. Peroxide Number vs Stress Time - Fuel 8	35
9	Aver. Peroxide Number vs Stress Time - Fuel 9	36
10	Aver. Peroxide Number vs Stress Time - Fuel 4 Expanded Scale	37
11	Aver. Peroxide Number vs Stress Time - Fuel 5 Expanded Scale	38
12	Aver. Peroxide Number vs Stress Time - Fuel 6 Expanded Scale	39
13	Aver. Peroxide Number vs Stress Time - Fuel 7 Expanded Scale	40
14	Aver. Peroxide Number vs Stress Time - Fuel 9 Expanded Scale	41

TABLES

Table		Page No.
1	Test Fuels	11
2	Participating Laboratories	12
3	Results of 65°C Accelerated Test	13
4	Variability of Triplicate Fuel Samples	22
5	Control Sample Results	25
6	Accelerated Test Time Needed to Distinguish Between Stable and Unstable Jet Fuels	27

RESULTS OF THE THIRD CRC COOPERATIVE TEST PROGRAM ON HYDROPEROXIDE POTENTIAL OF JET FUELS

I. INTRODUCTION

The third cooperative hydroperoxide test program was carried out under Coordinating Research Council (CRC) auspices to investigate further the development of an accelerated test for hydroperoxide potential of jet fuels using for analysis ASTM D3703-85 ("Standard Test Method for Peroxide Number of Aviation Turbine Fuels"). This program was agreed upon and authorized by the CRC Panel on Hydroperoxide Potential at its meeting April 29, 1985 at Dayton, Ohio. This work is of interest especially for hydro-treated fuels and fuels from non-petroleum sources.

In the first test program, which was carried out in 1982 by six laboratories, selected fuels were stored at 100°C for 7 days and analyzed periodically for peroxides. Results showed wide variations between laboratories and between duplicate samples. These results plus subsequent work at NRL at 43°, 65°, and 80°C (1) indicated that an accelerated test at 80° or 100°C is not predictive of behavior at lower temperatures, including ordinary fuel storage conditions.

In the second round robin program (2), conducted in 1984, five fuels were stored at 65°C for 56 days with intermediate sampling times at 1,3,7,14,21 and 35 days. Procedures were tightened in an attempt to reduce excessive variability of results. Unfortunately some of the fuels sought were not obtained and of the five fuels used, four contained antioxidants and in 8 weeks at 65°C did not exceed 0.5 meq/kg of hydroperoxides. Thus this program was unsatisfactory. However, some data were obtained on the variability within laboratories, between duplicate samples of the same fuel, and between labs. Additional work was done by two laboratories on the effect of reaction time and the substitution of Freon 113 (1,1,2-trichloro-1,2,2-trifluoroethane) solvent for carbon tetrachloride. Also some observations on the iodometric titration were collected.

A calibration sample, consisting of stable t-butyl hydroperoxide dissolved in a very stable jet fuel, was included in the second round robin in order to distinguish variability due to the analytical method from that due to the accelerated test. Thus, analysis of this control sample was free from (a) the complexity

of having a mixture of peroxides of different types and (b) changes due to accelerated storage. It appears that there are no known data of record to support the "repeatability (r)" and "reproducibility (R)" (15% and 60% respectively) stated for the ASTM analytical method. Results from the calibration sample provided such data.

In the second round robin, the within-labs spreads (the immediate repeatability, based on 2 sets of quadruplicates) for the calibration standard varied from 0.2 to 15.4% with an average of 6.2%. The corresponding pooled standard deviation and the value of "r" were 3.5% and 9.8% respectively. The lab averages for peroxide number (the reproducibility between labs) varied from 9.20 to 10.51 meq/kg giving a spread of 13%. The corresponding standard deviation was 14.6% and thus "R" was 41%. These relatively low values indicated that the analytical method contributed only a minor component to the variability of the accelerated test results.

II. EXPERIMENTAL

The third test program was planned to enlarge on the previous programs and to ensure that a majority of the sample fuels would develop significant levels of peroxides (more than 1 meq/kg). For the latter goal, fuels were selected carefully from a broader range of sources and it was stipulated that they had to have been hydrotreated and contain no anti-oxidant. Samples chosen included JP-5's, Jet A's, blending stocks and a shale JP-4. These are identified in Table 1. Ten or 50 gallons of each fuel were obtained and 2/3 gallon each was supplied to the laboratories. Each fuel was stated by the supplier to contain no anti-oxidant. Fuels #5 and #8 were labelled as having no additives. Fuel samples were shipped under argon but were to be aerated before putting in the oven. The plan called for nine fuels and eight laboratories, as compared to the 5x6 matrix in the second round robin, and 3 sample bottles of each fuel instead of 2. This was to permit improved statistical conclusions. The instructions called for putting 400 ml samples in each bottle so that at least 50 ml could be taken at each sampling time. Note that only one analysis per bottle was made at each time. One analysis on each of three identical samples (bottles) at each time is more useful than triplicate analyses on one bottle. Thus each laboratory set up 27 samples instead of 10 in Round Robin 2, but the number of sampling times was 6 instead of 8. It was intended originally to limit the time at 65°C to two or three weeks. However, screening tests at NRL indicated that a longer time was needed in order to develop more peroxides. Thus, the time was extended to 6 weeks with analyses at 0, 7, 14, 21, 28 and 42 days. Greater access of samples to atmospheric oxygen while in the oven was provided in this program. A calibration sample, as described above for the previous program, was furnished again to check the variability due to the analytical method alone (and also biases between laboratories). The hydroperoxide level this time was approximately 3

instead of 10 meq/kg. Instructions and notes on procedure were distributed to participants in a letter dated April 7, 1986 (3). Table 2 lists the laboratories and personnel involved.

III. RESULTS

Analytical results of the accelerated test program are shown in Table 3 together with averages. The averages are graphed in Figs. 1-9. These results should be studied in comparison with the results of the second round robin, which were reported to the Coordinating Research Council October 29, 1984 (2). Note that Texaco conducted duplicate rather than triplicate bottle tests and duPont omitted analysis at 3 weeks. It is apparent that appreciable variation exists between bottles and between laboratories. Development of hydroperoxides in fuels involves free radical reactions among hundreds of compounds and appears to be inherently variable. The components of variability are discussed in the following sections. These include variability of the analytical method, variability between triplicate fuel samples within one laboratory, and variability between laboratories. In spite of such variability it appears, on careful examination of the results, that the 65°C test can distinguish between stable and unstable fuels in about three weeks (see Section F below).

A. Analytical Variability

The non-stressed control sample (see below) provided the primary data on variability attributable to the iodometric analytical method. Additional information was obtained from duplicate fuel analyses. Such duplicate results (same bottle, same day) were reported by Texaco, NIPER and Exxon (see Table 3). (Repeat analyses had been requested whenever a set of triplicate bottles varied by more than 15% or 0.3 meq/kg in the case of results below 1 meq/kg). The close agreement of these 76 pairs of data supports strongly the conclusion that the differences between bottles (see below) are real. An analysis of the data is as follows:

Range of differences between duplicates ^a	0-40%
Average difference	5.0%
Pooled standard deviation of individual values ^b	6.0%
Repeatability r ^c	16.8%

$$^a \frac{\text{difference}}{\text{mean}} \times 100$$

$$^b \text{ P.S.D.} = \sqrt{\frac{\sum d^2}{2n}} \quad \text{where } d = \% \text{ difference and } n = \text{no. of pairs (4)}$$

$$^c r = 2\sqrt{2} \times \text{std. dev.}$$

Note that differences and standard deviations must be shown on a percentage rather than an absolute basis because peroxide values vary with fuel and time. The agreement shown by these data represents the repeatability of the analytical method - as applied to jet fuels. The repeatability "r", as used by ASTM, can be calculated from the standard deviation as shown above. It is defined as "the difference between two successive test results, obtained by the same operator with the same apparatus under constant operating conditions on identical test material would, in the long run, in the normal and correct operation of the test method, exceed the following values only in one case in twenty: $0.15X$ where X = the average of the two test results." The 16.3% above compares closely with 12.2% for the control sample in this round robin, 9.8% in the second round robin (see below), and 15% stated in ASTM Method D-3703-85 for "r".

Pratt & Whitney and Southwest Research Institute also carried out some repeat analyses 1-4 days later than the originals. Since the peroxide values were changing very rapidly with stress time, it is not possible to compare these paired values. However, when graphed as a function of the number of days at 65°C, the Pratt & Whitney data support the conclusion above that the bottle differences do represent real differences in reaction rates between bottles and are not due to sampling or titration techniques. Furthermore the percent spreads for repeat sets of triplicates were as great as for the initial set. On the other hand, the Southwest Research analyses showed appreciable decreases as well as increases with the additional 1-3 days at 65°C.

B. Variability of Triplicate Fuel Samples (Bottles)

Variations between triplicate bottles as expected were significantly greater than the analytical variability. It is obvious that bottle differences were real. These variations are shown in two ways. In Table 3, variations greater than 1.5 to 1 and greater than 3 to 1 are indicated by superscripts on the averages. Including cases where all three bottles were zero, and excluding a few cases where peroxide numbers were small and of questionable significance, 62% of variations were less than 1.5 to 1, 17% were 1.5-3 to 1 and 13% were greater than 3 to 1. Table 4 shows the percent difference between the highest and lowest of each set of triplicates. These vary from 0 to 302% of mean with an average of 45% (40% is equivalent to 1.5 to 1). The average spread between duplicate bottles in the previous round robin was 15%. This was based on fewer data and is not altogether comparable here. Triplicate variability by either method above is only a little higher (possibly not significantly) for the high peroxide fuels (#4-7) and slightly lower for the low fuels (#1, 2, 3, 8, 9). The values in Table 4 varied significantly between labs as follows (for all fuels and stress times):

<u>Laboratory</u>	<u>Mean</u>	<u>Std. Dev.</u>
NRL	66%	84%
NAPC	68	93
P&W	16	21
duPont	16	22
Texaco	26	22
NIPER	77	82
SwRI	60	77
EXXON	<u>38</u>	<u>57</u>
average	45%	

Note: "Mean" and "Std. Dev." refer to all the values listed in Table 4 for each laboratory.

Also the repeatability "r" (i.e., within sets of triplicates, or within laboratories) was calculated for some representative combinations of fuel and stress time where the peroxide numbers were not zero. Values obtained from the data at four weeks, for example, varied from 20 to 461% of mean with an average of 209%. Note that "r" is calculated as $2\sqrt{2}$ times the pooled standard deviation of triplicate sets, s_w .

C. Variation Between Laboratories

Variations between laboratories were appreciable and greater than the variability of triplicates. Also they were greater than in the second round robin, which produced much less data. Averages for each fuel, time period and laboratory are listed in Table 3 and plotted in Figures 1-9. Some points or labs in the plots appear to be outliers, e.g., NAPC - fuels 2, 3, 8, 9 and Texaco -fuel 5. A rough measure of the interlab variability is the ratio of the highest to the lowest lab using the averages of triplicates. This ratio exceeded 10 in a number of sets and even exceeded 100 in a few cases. In Round Robin 2 the ratios were mostly in the range 3:1 to 10:1. The current data also show that with longer stress times and consequently higher peroxide levels the ratio did not increase. In other words the relative variation between labs was as great at low peroxide levels as at high levels. The reproducibility "R" for all labs was calculated for particular combinations of fuel and stress time. Using all fuels at four weeks, R was 311-909% of mean with an average of 515%. "Mean" is the mean of the eight labs for each fuel.

The data reveal that biases between laboratories do exist, i.e., some laboratories fairly consistently found higher or lower peroxide than others. For example, duPont and Pratt & Whitney were lowest in almost all cases. Texaco and NAPC were highest with five of the fuels and NIPER with three. However, NAPC was high with the low fuels and low with the high fuels while Texaco

and NIPER were high with the high fuels and low with the low fuels. NAPC's high values at 6 weeks may be related to the fact that analyses at 6 weeks (and "C" bottles at 4 weeks) were performed by a different operator. With fuels #6 and #7 there was a sharp division into a high group (Texaco, NIPER, NRL) and a low group (duPont, Pratt & Whitney, NAPC). These results correlate generally with those from the control sample (see below).

Fuels which peroxidized readily were replotted in Figures 10-14 on an expanded scale. With fuels #5-7 the labs found considerable variation in induction time. "Induction time" refers to the time (1-4 weeks here) when the production of peroxides changed from a slow rate to a fast rate. This variable induction period explains much of the variation between laboratories.

D. Control Sample

As indicated above, a control sample was prepared and portions were distributed to the labs to obtain data on the repeatability and reproducibility of the analytical method used in the accelerated test program. The original data are listed in Table 5 with averages and percent range added. Corresponding times for stressed samples are noted only for identification purposes. The control samples were directed to be stored in a refrigerator and no change with time was expected and none was found except in the case of NAPC. Here use of three different operators may have been a factor. The percent range or spread of each set of quadruplicates varied from 2.0% to 17.0% with an average of 7.3%. Compare with the average of 6.2% in Round Robin 2. The pooled standard deviation of individual values (s_w) was 0.0905 or 4.3% of the mean peroxide number of 2.09 meq/kg. This agrees well with the 6.0% shown above for duplicate fuel analyses. The comparable value of s_w in the second round robin was 3.5%. Repeatability "r" for the current data then equals $2\sqrt{1}s_w = 12.2\%$. The foregoing refers to "immediate repeatability". These values may be compared with the values for duplicate fuel analyses above, which also indicate the immediate repeatability of the analytical method. Calculated values for non-immediate repeatability (i.e., the variation between averages at different times, as 2 and 4 weeks, at the same lab) were 2.2% average range and 1.7% for the pooled standard deviation.^a

Reproducibility (the variation between labs) is shown by the following data (extracted from Table 5):

$$a \quad \frac{\sqrt{\frac{\sum d^2}{2n}}}{\text{grand aver.}} \times 100$$

<u>Laboratory</u>	<u>Average Peroxide No.</u>
NAPC (2, 6 weeks)	3.33 meq/kg
SWRI	2.41
NIPER	2.35
NRL (25 ml)	2.31
Texaco	2.14
P&W	2.04
DuPont	1.87
EXXON	1.54
Grand average (excl. NAPC)	2.09

Statistical values calculated from the data in Table 5 and corresponding values for Round Robin 2 are shown below:

<u>Statistic</u>	<u>Round Robin 3</u>	<u>Round Robin 2</u>
Grand average, meq/kg	2.09	9.91
Spread between averages	0.87 = 42%*	1.31 = 13%*
s_b^{**}	40.6%	14.6%
Reproducibility R ($2\sqrt{2} s_b$)	115%	41%
Aver. spread within labs	7.3%	6.2%
s_w	4.3%	3.5%
Repeatability r ($2\sqrt{2} s_w$)	12.2%	9.8%

* % of average peroxide number for all labs (2.09 and 9.91)

** Std. dev. between labs. Calculated as shown in reference (4), p. 32.

Note: NAPC data in Round Robin 3 were excluded.

Obviously the variation between labs is much greater than that within labs. See also the comments above under interlab variation of fuel results concerning laboratories that gave more or less consistently high or low results. The reproducibility R = 115% above is disappointingly high and is to be compared with the 41% found in the second round robin and the 60% stated officially for ASTM Method D-3703. The calculation of R from s_b depends on the definition of R, namely, "The difference between two single and independent results, obtained by different operators working in different laboratories on identical test material would, in the long run, in the normal and correct operation of the test method, exceed the following values only in one case in twenty: $R = 0.60X$, where X = the average of two test results."

E. Effect of Sample Size

Some observations on the control sample (Table 5) indicated that peroxide number varies (inversely) with sample size:

<u>Laboratory</u>	<u>Sample Size</u>	<u>Average Peroxide No.</u>
NRL	10 ml (8.06 g)	2.583
	25 ml (20.16 g)	2.310
	50 ml (40.3 g)	2.060
NIPER	15 g	2.473
	21 g	2.370
	23 g	2.324
	26 g	2.311
	28 g	2.310
	31 g	2.264

The NRL and NIPER data give a single smooth plot for P.N. vs. sample size. Other laboratories did not report sample size. Unrelated experience at NRL (5) with peroxide determination in fuels has shown no such effect. This effect may explain some of the differences between laboratories.

F. Evaluation of Go/No-Go Test Potential

The military specification for Aviation Turbine Fuel (6) sets a peroxide number maximum of 1.0 meq/kg for JP-5. We therefore examined the Round Robin 3 data to evaluate the P. N. requirement of 1.0 vs the various test times at 65°C.

Table 6 lists the number of laboratories which exceeded the 1.0 limit at the different test times. A high number, 7 or 8, indicates agreement between labs with respect to failure (P.N. >1.0). Note that fuels 4 and 6 were rated as failing in three weeks by all labs (7 of 7) and fuels 5 and 7 failed on most tests (6 of 7). Further, all labs failed these four fuels (4,5,6 & 7) at four weeks. However, two fuels (1 and 9) which showed good stability at three weeks or less, were rated as fails by one lab each at four weeks. At longer times (6 weeks), additional failures were observed.

On the basis of the bulk of the data, fuels 1,2,3,8 and 9 can be classified as satisfactory and fuels 4,5,6 and 7 rated as unacceptable. At stress times of three or four weeks, a peroxide number of 1.0 meq/kg is a good criterion for distinguishing the two sets of fuels. Although other values of the P.N. could be considered to improve the distinction between good and bad fuels, a P. N. of 1.0 is favored on the basis of elastomer tests (7).

Summarizing for the two sets of fuels:

- (a) At 3 weeks, poor fuels exceeded a P.N. of 1.0 in 26 of 28 fuel/lab combinations
- (b) At 3 weeks, good fuels exceeded a P.N. of 1.0 in 0 of 28 fuel/lab combinations
- (c) At 4 weeks, poor fuels exceeded a P.N. of 1.0 in 32 of 32 fuel/lab combinations
- (d) At 4 weeks, good fuels exceeded a P.N. of 1.0 in 2 of 31 fuel/lab combinations.

Data from Round Robin 2 supports the Go/No-Go findings from the current exercise. In the earlier cooperative tests, one fuel was markedly unstable at 65°C and four were classified as stable. All six labs participating in that exercise found more than 1.0 meq/kg of hydroperoxide for the one bad fuel at three weeks (also at 2 weeks) and none of the labs found more than 1.0 meq/kg for the other four fuels at three weeks. One lab failed one of the acceptable fuels at both 5 and 8 weeks.

IV. CONCLUSIONS

Based on the cooperative work reported herein, the 65°C accelerated test readily distinguishes between stable and unstable fuels in approximately 3 weeks stress time. Consequently it appears useful for screening jet fuels for their long-time oxidation stability. Thus this test is recommended as a Go/No-Go test and this is what was sought in these studies. On the other hand the variability of results within and between laboratories would seem to preclude its use as a precise quantitative tool.

In more detail, the nine fuels examined in this cooperative program can be divided into five acceptable and four unacceptable fuels on the basis of the overall pattern of fuel behavior. Using a criterion of a P.N. of 1.0 meq/kg, six or seven labs out of seven successfully distinguished between the two groups of fuels at three weeks and eight out of eight at four weeks.

Data were obtained on the repeatability r (within laboratories) and reproducibility R (between laboratories) of the analytical method, ASTM D3703, applied to jet fuels by measurements on a non-heat-stressed control sample. The value for r was 12% of mean. This was confirmed by the corresponding value of 12% for 76 pairs of duplicate fuel analyses. On the other hand the repeatability in the accelerated test between triplicate stressed fuel samples within laboratories was 20-46% of mean in selected cases of fuel and stress time. The reproducibility R between laboratories was 272-909% of mean. Some of the latter variability was due to laboratory bias, i.e., some labs were

consistently high or low. Thus the analytical variability was small while variability between identical stressed fuel samples and between labs was great.

V. REFERENCES

1. R. N. Hazlett, J. M. Hall, C. J. Nowack, and L. Craig, "Hydroperoxide Formation in Jet Fuels," in Proceedings of Conference on Long Term Storage Stabilities of Liquid Fuels, Tel Aviv, Israel, pp. B132-148, Oct. 1983.
2. "Results of the Second CRC Cooperative Test Program on Hydroperoxide Potential of Jet Fuels," NRL Letter 6180-1084:JMH:cm, 29 October 1984.
3. "Procedure for the Third CRC Test Program," NRL ltr. to Participants in the Third CRC Cooperative Test Program on Hydroperoxide Potential of Jet Fuels, 7 April 1986
4. J. H. Youden, "Statistical Methods for Chemists," Huntington, NY, Krieger, 1977.
5. R. N. Hazlett, J. V. Cooney and E. J. Beal, "Mechanisms of Syncrude/Synfuel Degradation, First Annual Report," June 1983. NRL Report for DOE under contract No. DE-AI-81BC10525, Rpt. No. DOE/BC/10525-4.
6. MIL-T-5624L with Amendment 2, "Turbine Fuel, Aviation, Grades JP-4 and JP-5," 10 August 1983.
7. R. H. Shertzer, "Aircraft Systems Fleet Support/Organic Peroxides in JP-5 Investigation," Final Report NAPC-LR-78-10, Naval Air Propulsion Center, Trenton, NJ, 27 September 1978.

Table 1 - Test Fuels

<u>Fuel No.</u>	<u>Type</u>	<u>Source</u>	<u>Hydrotreatment</u>
1	Jet A	Texaco	Mildly H-treated
2	Blending Stock	Shell, Thornton, UK	Moderately H-processed
3	Blending Stock	Shell, Thornton, UK	Severely H-processed
4		Petro-Canada, Montreal	Hydrotreated
5	Shale JP-4	Wright-Pat. AFB	Hydrotreated
6	Jet A Blending Stock	ESSO Petrol. Corp. Res. Div., Sarnia, Ontario	Hydrofined
7	Jet A Blending Stock	ESSO Petrol. Corp. Res. Div., Sarnia, Ontario	Hydrocracked
8	JP-5	EXXON, Baton Rouge	No H-treatment
9	JP-5	EXXON, Benicia	Mod. H-treatment

Table 2 - Participating Laboratories

1.	NRL	Naval Research Laboratory	Jim Hall
2.	NAPC	Naval Air Propulsion Center	Lynda Turner
3.	P&W	Pratt & Whitney, United Technologies Corporation	Linda Neubauer Paul Warner
4.	duPont	E. I. duPont de Nemours & Co.	Tayman Phillips
5.	TEX	Texaco, Inc.	Salvatore Rand
6.	EXXON	EXXON Research & Engineering Company	William Taylor
7.	SWRI	Southwest Research Institute	Pat Cuellar
8.	NIPER	National Institute for Petroleum and Energy Research	John Goetzinger

Table 3 - Results of 65°C Accelerated Test

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 1 - JET A (Texaco)							
NRL	A	.00	.15	.18	.26	.32	.44
	B	.00	.10	.18	.26	.74	.54
	C	.00	.12	.22	.27	.38	.51
	aver.	.00	.12	.20	.26	.48 ^b	.50
NAPC	A	.00	.00	.41	.55	.76	1.94
	B	.00	.00	.51	.56	.64	2.03
	C	.00	.00	.44	.85	1.51	1.59
	aver.	.00	.00	.45	.65	.97 ^b	1.85
P & W	A	.00	.04	.06	.10	.16	.15
	B	.00	.04	.07	.11	.14	.16
	C	.00	.02	.07	.11	.12	.16
	aver.	.00	.03 ^b	.07	.11	.14	.16
duPont	A	.00	.03	.10		.16	.22
	B	.00	.04	.09		.09	.12
	C	.00	.04	.09		.12	.18
	aver.	.00	.04	.09		.12 ^b	.17 ^b
TEX	A	.00	.12	.49	.98	2.22	3.70
				.45		2.31	3.78
	B	--	.07	.34	.77	1.58	2.92
	aver.	.00	.10 ^b	.42	.88	1.94	3.32
NIPER	1	.00	.07	.08	.08	.13	.12
	2	.00	.07	.08	.11	.13	.13
	3	.00	.10	.13	.15	.16	.15
	aver.	.00	.08	.09 ^b	.11 ^b	.14	.13
SWRI	1	.01	.30	.27	.55	.41	.43
	2	<.01	.43	.56	.14	.93	.47
	3	<.01	.20	.37	.52	.39	.42
	aver.	<.01	.31 ^b	.40 ^b	.40 ^a	.58 ^b	.44
EXXON	A	.00	.15	.15	.29	.28	.15
	B	.00	.13	.22	.34	.27	.18
	C	.00	.10	.18	.52	.32	.25
	aver.	.00	.13	.18	.38 ^b	.29	.19 ^b

^a Ratio of highest to lowest bottle > 3

^b Ratio of highest to lowest bottle 1.5-3

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 2 - SHELL, MOD. PROC'D BLENDING STOCK							
NRL	A	.00	.00	.00	.00	.20	1.03
	B	.00	.00	.00	.05	.21	.76
	C	.00	.00	.00	.00	.16	.99
	aver.	.00	.00	.00	.02	.19	.93
NAPC	A	.00	.00	.00	.00	.49	4.99
	B	.00	.00	.00	.00	.00	1.20
	C	.00	.00	.00	.00	.00	1.64
	aver.	.00	.00	.00	.00	.16 ^a	2.61 ^a
P&W	A	.00	.00	.00	.00	.04	.14
	B	.00	.00	.00	.00	.05	.14
	C	.00	.00	.00	.00	.05	.15
	aver.	.00	.00	.00	.00	.05	.14
duPont	A	.00	.00	.00		.00	.24
	B	.00	.00	.00		.00	.29
	C	.00	.00	.00		.06	.32
	aver.	.00	.00	.00		.02 ^a	.28
TEX	A	.00	.00	.00	.00	.10	.56
	B	-	.00	.00	.02	.14	.78
	aver.	.00	.00	.00	.01	.12	.82
NIPER	4	.00	.00	.00	.07	.27	.92
							.96
	5	.00	.00	.00	.18	.36	.95
							.96
	6	.00	.00	.19	.42	.74	1.45
	aver.	.00	.00	.06 ^a	.22 ^a	.46 ^b	1.12 ^b
SWRI	1	.03	<.01	<.01	.64	1.09	2.16
	2	<.01	<.01	<.01	<.01	.04	.70
	3	<.01	<.01	<.01	<.01	<.01	.63
	aver.	.01 ^a	<.01	<.01	.21 ^a	.38 ^a	1.16 ^a
EXXON	A	.00	.00	.01	.00	.00	.27
	B	.00	.00	.00	.00	.00	.14
	C	.00	.00	.00	.00	.00	.12
	aver.	.00	.00	.00	.00	.00	.18 ^b

^a Ratio of highest to lowest bottle >3

^b Ratio of highest to lowest bottle 1.5-3

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 3 - SHELL, SEV. PROC'D. BLENDING STOCK							
NRL	A	.00	.00	.00	.00	.08	.21
	B	.00	.00	.00	.01	.07	.40
	C	.00	.00	.00	.06	.11	.48
	aver.	.00	.00	.00	.02 ^a	.09	.36 ^b
NAPC	A	.00	.00	.00	.00	.33	.01
	B	.00	.00	.00	.00	.18	.01
	C	.00	.00	.00	.17	1.21	1.97
	aver.	.00	.00	.00	.06 ^a	.57 ^a	.66 ^a
P & W	A	.00	.00	.00	.05	.07	.12
	B	.00	.00	.00	.05	.08	.11
	C	--	.00	.00	.05	.08	.12
	aver.	.00	.00	.00	.05	.08	.12
duPont	A	.00	.00	.05		.07	.11
	B	.00	.00	.05		.07	.10
	C	.00	.00	.05		.08	.10
	aver.	.00	.00	.05		.07	.10
TEX	A	.00	.00	.03	.06	.09	.24
				.00			
	B	--	.00	.04	.06	.09	.27
	aver.	.00	.00	.03	.06	.09	.26
NIPER	7	.00	.00	.00	.00	.04	.11
							.11
	8	.00	.00	.00	.00	.00	.09
	9	.00	.04	.00	.00	.08	.22
	aver.	.00	.01	.00	.00	.04 ^a	.14 ^b
SWRI	1	.01	<.01	<.01	<.01	<.01	<.01
	2	<.01	<.01	<.01	<.01	<.01	<.01
	3	<.01	<.01	<.01	<.01	<.01	<.01
	aver.	<.01	<.01	<.01	<.01	<.01	<.01
EXXON	A	.00	.00	.00	.07	.05	.10
	B	.00	.00	.00	.00	.06	.07
	C	.00	.00	.00	.00	.04	.09
	aver.	.00	.00	.00	.02 ^a	.05	.09

^a Ratio of highest to lowest bottle >3

^b Ratio of highest to lowest bottle 1.5-3

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 4 - PETRO-CANADA							
NRL	A	.00	1.56	31.4	103.0	207.5	361.2
	B	.00	7.32	64.5	158.0	257.0	460.8
	C	.00	2.89	37.2	156.2	236.4	345.0
	aver.	.00	3.92 ^a	44.4 ^b	139.1 ^b	233.6	389.0
NAPC	A	.00	.00	25.1	67.4	94.6	297.8
	B	.00	.00	27.3	50.3	40.0	110.7
	C	.00	.00	24.6	142.2	288.9	317.5
	aver.	.00	.00	25.7	86.6 ^b	141.1 ^a	242.0 ^b
P & W	A	.00	.14	11.9	96.1	237	471
	B	.00	.16	19.2	112.2	286	576
	C	--	.16	17.2	110.5	276	481
	aver.	.00	.15	16.1 ^b	106.3	266	509
duPont	A	.00	.18	7.45		27.6	46.6
	B	.00	.18	9.50		38.4	56.5
	C	.00	.17	8.80		29.1	106.5
	aver.	.00	.18	8.58		31.7	69.9 ^b
TEX	A	.00	5.48	58.1	174.8	237.3	374.3
			5.44	60.4	177.2	237.6	
				63.9			
	B	--	10.99	88.1	254.8	403.8	409.5
			11.74	76.3	260.1	409.4	
				87.1			
	aver.	.00	8.41 ^b	72.5	216.7	322.0	391.9
NIPER	10	.00	.41	34.3	127.8	269.6	430.5
					129.8		427.2
	11	.00	.00	9.9	64.4	241.9	445.6
					66.4		443.6
	12	.00	.51	39.4	154.9	319.8	459.8
				43.9	167.9		
	aver.	.00	.31	28.6 ^a	118.5 ^b	277.1	444.4
SWRI	1	.02	.95	24.7	101.4	167.7	527.7
	2	<.01	.93	30.6	97.4	167.9	643.5
	3	<.01	.97	26.0	106.4	160.9	381.1
	aver.	.01	.95	27.1	101.7	165.5	517.4 ^b
EXXON	A	.00	.00	8.70	38.1	65.0	83.0
	B	.00	.15	7.35	40.4	66.2	97.5
	C	.00	.03	4.38	31.8	64.5	75.3
	aver.	.00	.06 ^a	6.81 ^b	36.8	65.2	85.3

^a Ratio of highest to lowest bottle >3^b Ratio of highest to lowest bottle 1.5-3

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg Weeks Stressed at 65°C					
		0	1	2	3	4	6
		FUEL 5 - SHALE JP-4					
NRL	A	.00	.06	.11	.91	8.01	42.1
					1.11		
	B	.00	.06	.08	.57	26.43	107.2
	C	.00	.08	4.65	25.95	63.79	110.7
	aver.	.00	.07	1.62 ^a	9.18 ^a	32.74 ^a	86.7 ^b
NAPC	A	.00	.00	.36	4.09	11.07	106.8
	B	.00	.00	.36	4.60	12.67	10.2
	C	.00	.00	.42	4.11	27.46	38.2
	aver.	.00	.00	.38	4.27	17.07 ^b	51.7 ^a
P & W	A	.00	.00	.12	2.6	20.4	97.1
	B	.00	.00	.12	2.3	19.1	110.6
	C	-	.00	.31	3.5	24.8	138.2
	aver.	.00	.00	.18 ^b	2.8 ^b	21.4	115.3
duPont	A	.00	.00	.07		2.07	52.4
	B	.00	.00	.06		1.89	44.2
	C	.00	.00	.07		1.78	52.8
	aver.	.00	.00	.07		1.91	49.8
TEX	A	.00	.08	4.54	28.3	75.4	257.5
				4.56	28.4	74.8	
	B	--	.18	8.18	35.4	90.9	278.8
				8.01	35.7	90.9	
	aver.	.00	.13 ^b	6.30 ^b	31.9	83.0	268.2
NIPER	13	.00	.00	.00	.03	.12	5.3
							5.5
	14	.00	.00	.00	.06	.33	33.9
							46.7
	15	.00	.00	.09	.72	13.9	105.8
SWRI						19.9	106.1
	aver.	.00	.00	.03 ^a	.27 ^a	5.78 ^a	50.5 ^a
	1	.06	<.01	.20	1.05	5.88*	60.0
EXXON	2	<.01	.04	.33	1.08	15.91	50.9
	3	<.01	.07	.29	.94	11.82	47.8
	aver.	.02 ^a	.04 ^a	.27 ^b	1.02	13.87	52.9
EXXON	A	.00	.00	.15	17.2	48.9	67.5
					18.6	49.7	
	B	.00	.00	.13	4.41	19.9	
					4.60	18.7	48.8
	C	.00	.05	2.17	14.1	29.3	
EXXON					24.2	28.0	51.5
	aver.	.00	.02	.82 ^a	12.2 ^a	32.4 ^b	55.9

^a Ratio of highest to lowest bottle >3^b Ratio of highest to lowest bottle 1.5-3

* Sample size too large. Omit.

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 6 - JET A BLENDING STOCK, HYDROFINED							
NRL	A	.10	.53	1.58	2.71	5.55	70.7
	B	.10	.60	1.21	2.30	6.66	89.6
	C	.10	1.24	6.41	30.04	81.9	297.7
						74.0	
	aver.	.10	.79 ^b	3.07 ^a	11.7 ^a	30.0 ^a	152.7 ^a
NAPC	A	.39	.00	2.69	5.13	5.14	66.5
	B	.38	.00	2.99	4.91	4.66	51.3
	C	.37	.00	2.65	4.90	10.18	38.2
	aver.	.38	.00	2.78	4.98	6.66 ^b	52.0 ^b
	P & W	A	.08	.41	.90	1.9	3.8
B		.09	.39	.91	1.9	4.2	19.0
C		--	.39	.84	1.8	3.9	19.1
aver		.09	.40	.88	1.9	4.0	20.1
duPont		A	.09	.70	1.80		7.75
	B	.09	.76	1.93		6.20	44.5
	C	.09	.66	1.78		6.75	22.1
	aver.	.09	.71	1.84		6.90	30.1 ^b
	TEX	A	.08	1.22	6.66	23.4	35.1
				6.62	23.7	35.7	135.8
B		.09	.98	4.50	16.7	46.6	177.7
				4.56	16.7	46.7	183.2
aver.		.09	1.10	5.59	20.1	41.0	159.2
NIPER	16	.09	.47	1.04	1.72	3.70	20.1
							21.6
	17	.09	1.44	3.03	16.08	63.6	225.3
					18.73	70.6	223.3
	18	.09	.68	2.11	5.99	18.1	196.8
				5.42	17.5	184.4	
aver.	.09	.86 ^a	2.06 ^b	8.3 ^a	29.5 ^a	145.2 ^a	
SWRI	1	.20	1.09	1.63	5.54	8.85	88.7
	2	.01	1.18	1.86	6.63	10.70	81.9
	3	.11	.94	2.02	6.17	11.33	110.1
	aver.	.14 ^a	1.07	1.84	6.11	10.29	93.6
	EXXON	A	.08	.52	1.11	1.83	3.01
B		.07	.46	1.17	1.90	3.05	14.3
C		.07	.49	1.17	1.77	2.73	11.7
aver.		.07	.49	1.15	1.83	2.93	14.1

^a Ratio of highest to lowest bottle >3

^b Ratio of highest to lowest bottle 1.5-3

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 7 - JET A BLENDING STOCK, HYDROCRACKED							
NRL	A	.00	.13	.41	.35	2.68	102.3
	B	.00	.14	.62	1.63	3.51	122.2
	C	.00	.16	.43	1.15	3.64	79.7
	aver.	.00	.14	.49 ^b	1.04 ^a	3.28	101.4 ^b
NAPC	A	.00	.00	.17	2.38	4.07	56.4
	B	.00	.00	1.08	3.01	3.77	34.9
	C	.00	.00	.54	1.78	5.31	12.8
	aver.	.00	.00	.60 ^a	2.39 ^b	4.38	34.7 ^a
P & W	A	.00	.04	.21	1.10	4.2	39.9
	B	.00	.04	.15	.69	2.6	23.4
	C	--	.04	.20	.80	3.8	29.1
	aver.	.00	.04	.19	.86 ^b	3.5 ^b	30.8 ^b
duPont	A	.00	.13	.35		2.75	26.9
	B	.00	.08	.37		4.12	29.3
	C	.00	.15	.35		3.70	27.0
	aver.	.00	.12 ^b	.36		3.52	27.7
TEX	A	.00	.28	2.18	6.04	16.1	59.8
				2.07	6.07	15.7	59.3
	B	--	.25	2.70	3.61	24.2	156.2
	aver.	.00	.27	2.60	8.55	24.7	156.2
NIPER	19	.01	.06	.33	1.48	5.05	65.6
							65.2
	20	.01	.36	2.48	7.52	21.68	98.2
				2.94	8.51		96.8
	21	.00	.11	.63	5.67	23.25	161.0
					6.00		162.3
	aver.	.01	.17 ^a	1.22 ^a	5.11 ^a	16.7 ^a	108.2 ^b
SWRI	1	.14	.77	1.12	4.65	6.63	63.3
	2	.02	.44	1.09	3.72	6.51	62.0
	3	<.01	.42	1.20	3.65	9.91	55.0
	aver.	.05 ^a	.54 ^b	1.14	4.01	7.68 ^b	60.1
EXXON	A	.00	.00	2.33	6.94	16.6	50.8
				2.01		16.4	
	B	.00	.00	.96	6.23	17.2	50.1
				1.16		17.2	
	C	.00	.05	1.83	5.75	10.7	34.2
				1.61		11.0	
	aver.	.00	.02 ^a	1.65 ^b	6.31	14.9 ^a	45.0

^a Ratio of highest to lowest bottle >3^b Ratio of highest to lowest bottle 1.5-3

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 8 - JP-5 (EXXON, BATON ROUGE)							
NRL	A	.00	.05	.03	.06	.08	.08
	B	.02	.05	.03	.06	.10	.10
	C	.03	.04	.03	.04	.09	.09
	aver.	.02 ^a	.05	.03	.05	.09	.09
NAPC	A	.00	.00	.16	.00	4.22 ^c	.73
	B	.00	.00	.32	.00	.84	.77
	C	.00	.00	.17	.39	.95	1.12
	aver.	.00	.00	.22 ^b	.13 ^a	.90 ^a	.87 ^b
P & W	A	.00	.03	.06	.09	.07	.11
	B	.00	.02	.06	.09	.07	.11
	C	--	.04	.06	.09	.08	.11
	aver.	.00	.03 ^b	.06	.09	.07	.11
duPont	A	.00	.00	.00		.03	.02
	B	.00	.00	.00		.00	.00
	C	.00	.00	.00		.00	.00
	aver.	.00	.00	.00		.01 ^a	.01 ^a
TEX	A	.01	.07	.14	.14	.17	.18
	B	.02	.05	.09	.13	.23	.20
	aver.	.02 ^b	.06	.12 ^b	.14	.20	.19
NIPER	22	.02	.05	.06	.06	.07	.08
	23	.02	.06	.08	.08	.11	.07
	24	.03	.05	.08	.06	.05	.07
	aver.	.02	.05	.07	.07	.08 ^b	.07
SWRI	1	<.01	.20	.02	.11	<.01	.10
	2	<.01	.18	.17	.16	.12	.22
	3	<.01	.12	.12	.20	.41	.19
	aver.	<.01	.17 ^b	.14 ^b	.16 ^b	.18 ^a	.17 ^b
EXXON	A	.00	.07	.08	.12	.06	.08
	B	.00	.04	.03	.10	.10	.07
	C	.01	.05	.09	.09	.07	.09
	aver.	.00	.05 ^b	.07 ^a	.11	.07 ^b	.08

^a Ratio of highest to lowest bottle >3

^b Ratio of highest to lowest bottle 1.5-3

^c Exclude this outlier.

Table 3 (continued)

LAB	Bottle No.	Peroxide Number, meq/kg					
		Weeks Stressed at 65°C					
		0	1	2	3	4	6
FUEL 9 - JP-5 (EXXON, BENICIA)							
NRL	A	.00	.00	.16	.39	.40	.79
	B	.00	.00	.19	.30	.37	1.75
	C	.00	.07	.24	.29	.43	.92
	aver.	.00	.02 ^a	.20	.33	.40	1.15 ^b
NAPC	A	.00	.00	.00	.51	1.05	8.72
	B	.00	.00	.00	.40	.53	9.61
	C	.00	.00	.39	.64	1.70	1.94
	aver.	.00	.00	.13 ^a	.52 ^b	1.09 ^a	6.76 ^a
P & W	A	.00	.00	.05	.16	.25	.46
	B	.00	.00	.04	.15	.29	.49
	C	--	.00	.04	.18	.26	.50
	aver.	.00	.00	.04	.16	.27	.48
duPont	A	.00	.00	.04		.33	.47
	B	.00	.00	.04		.30	.49
	C	.00	.00	.04		.24	.53
	aver.	.00	.00	.04		.29	.50
TEX	A	.00	.01	.12	.21	.30	.55
							.56
	B	--	.02	.13	.22	.44	.92
							.94
	aver.	.00	.02 ^b	.13	.22	.37	.74 ^b
NIPER	25	.00	.00	.09	.14	.18	.43
	26	.00	.00	.18	.35	.49	.76
	27	.00	.00	.09	.20	.30	.49
	aver.	.00	.00	.12 ^b	.23 ^b	.32 ^b	.56 ^b
SWRI	A	.18	.20	.47	.85	.88	1.32
	B	<.01	.32	.58	1.02	1.02	1.03
	C	.03	.03	.53	.29	.53	.77
	aver.	.07 ^a	.18 ^a	.53	.72 ^a	.81 ^b	1.04 ^b
EXXON	A	.00	.00	.17	.34	.39	.55
	B	.00	.00	.10	.23	.30	.52
	C	.00	.00	.11	.16	.28	.58
	aver.	.00	.00	.13 ^b	.24 ^b	.32	.55

^a Ratio of highest to lowest bottle >3^b Ratio of highest to lowest bottle 1.5-3

Table 4 - Variability of Triplicate Fuel Samples

LAB	Percent Difference Between Triplicates*					
	Weeks Stressed at 65°C					
	0	1	2	3	4	6
FUEL 1						
NRL	0	41	21	4	88	20
NAPC	0	0	22	46	77	24
P & W	0	61	16	9	29	6
duPont	0	27	11		57	58
TEX		53	27	24	35	25
NIPER	0	38	52	52	21	24
SwRI	0	74	73	103	93	11
EXXON	0	39	38	61	17	53
FUEL 2						
NRL	0	0	0		26	29
NAPC	0	0	0	0	301	145
P & W	0	0	0	0	21	7
duPont	0	0	0			29
TEX		0	0		33	10
NIPER	0	0	302	159	104	46
SwRI		0	0	300	186	132
EXXON	0	0	0	0	0	83
FUEL 3						
NRL	0	0	0	261	44	75
NAPC	0	0	0	300	181	296
P & W	0	0	0	0	13	9
duPont	0	0	0		13	10
TEX		0	29	0	0	12
NIPER	0		0	0		93
SwRI	0	0	0	0	0	0
EXXON	0	0	0		40	33

* $\frac{\text{range}}{\text{mean}} \times 100$

Note: A range of 1.5:1 = 40% difference.
A range of 3:1 = 100% difference.

Table 4 (Continued)

LAB	Percent Difference Between Triplicates*					
	Weeks Stressed at 65°C					
	0	1	2	3	4	6
FUEL 4						
NRL	0	147	75	40	22	30
NAPC	0	0	11	106	176	90
P & W	0	13	45	15	18	21
duPont	0	6	24		34	36
TEX	0	64	32	38	52	9
NIPER	0		111	81	28	7
SWRI	0	4	22	9	4	51
EXXON	0		63	23	3	26
FUEL 5						
NRL	0	37	280	276	171	68
NAPC	0	0	16	12	10	187
P & W	0	0	100	43	27	36
duPont	0	0	15		15	17
TEX	0	77	57	23	19	6
NIPER	0	0		256	291	199
SWRI			48	14	30	23
EXXON	0		249	110	93	33
FUEL 6						
NRL	0	90	202	233	141	142
NAPC	5	0	12	5	30	54
P & W	12	5	10	5	10	16
duPont	0	14	8		22	74
TEX	12	22	38	34	23	28
NIPER	0	113	97	199	116	140
SWRI	173	22	21	18	14	20
EXXON	14	121	5	7	11	30

* $\frac{\text{range}}{\text{mean}} \times 100$

Note: A range of 1.5:1 = 40% difference.
A range of 3:1 = 100% difference.

Table 4 (Continued)

LAB	Percent Difference Between Triplicates*					
	Weeks Stressed at 65°C					
	0	1	2	3	4	6
FUEL 7						
NRL	0	21	43	123	29	42
NAPC	0	0	152	51	35	126
P & W	0	0	32	48	45	54
duPont	0	58	6		39	9
TEX	0	11	22	34	43	90
NIPER	0	167	195	127	109	89
SwRI	280	65	10	25	44	14
EXXON	0	300	64	19	42	37
FUEL 8						
NRL		31	22	40	20	20
NAPC	0	0	74	300	169	45
P & W	0	67	0	0	13	0
duPont	0	0	0			
TEX		33	43	7	30	11
NIPER		25	18	40	50	17
SwRI	0	47	107	57	228	71
EXXON	0	60	86	27	57	25
FUEL 9						
NRL	0		39	30	15	83
NAPC	0	0	300	46	107	113
P & W	0	0	23	18	15	8
duPont	0	0	0		31	12
TEX	0	67	8	5	38	49
NIPER	0	0	82	92	92	59
SwRI	245	161	21	115	60	53
EXXON	0	0	54	75	34	11

* $\frac{\text{range}}{\text{mean}} \times 100$

Note: A range of 1.5:1 = 40% difference.
A range of 3:1 = 100% difference.

Table 5 - Control Sample Results
Peroxide Number, meq/kg

1. NRL

3 Weeks		5 Weeks		
25 ml	10 ml	25 ml	10 ml	50 ml
2.350	2.633	2.254	2.489	2.060
2.339	2.519	2.248	2.690	
2.315		2.314		
2.431		2.233		
2.364		2.246		
2.360*	2.576	2.259	2.590	2.060
4.9%*	4.4%	3.6%	7.8%	

2. NAPC

2 Weeks	6 Weeks	9 Weeks
3.72	2.94	1.90
3.52	3.03	2.10
3.78		1.91
3.67	2.99	1.97
7.1%	3.0%	9.6%

3. P&W

1 Week	3 Weeks
2.02	2.05
2.03	2.01
2.13	2.02
2.02	2.05
2.05	2.03
5.4%	2.0%

4. duPont

6 Weeks
1.84
1.89
1.87
2.7%

5. Texaco

2 Weeks	4 Weeks
2.13	2.17
2.09	2.21
2.16	2.03
2.10	2.23
2.12	2.16
3.3%	9.3%

Table 5 (continued)

6. NIPER

<u>2 Weeks</u>	<u>4 Weeks</u>
2.310	2.331
2.425	2.287
2.334	2.353
2.473	2.324
	2.264
<u>2.386</u>	<u>2.312</u>
6.8%	3.8%

7. SWRI

<u>2 Weeks</u>	<u>4 Weeks</u>
2.25	2.30
2.54	2.23
2.50	2.60
2.63	2.22
<u>2.48</u>	<u>2.34</u>
15.3%	16.2%

8. EXXON

<u>Initial (8/27/86)</u>	<u>2 Weeks</u>
1.6783	1.5107
1.5844	1.2807
1.6635	1.3701
1.7252	1.5181
<u>1.6629</u>	<u>1.4199</u>
8.5%	17.0%

* The first value is the average and the second is the ratio of the range to the average as a percent.

Table 6 - Accelerated Test Time Needed to Distinguish
Between Stable and Unstable Jet Fuels

Fuel No.	No. of Labs With Peroxide Number Greater Than 1 meq/kg Weeks Stressed at 65°C				
	<u>1</u>	<u>2</u>	<u>3*</u>	<u>4</u>	<u>6</u>
1	0	0	0	1	2
2	0	0	0	0	3
3	0	0	0	0	0
4	2	8	7	8	8
5	0	2	6	8	8
6	2	7	7	8	8
7	0	4	6	8	8
8	0	0	0	0	0
9	0	0	0	1	3

*7 labs reported instead of 8.

Note: Fuels #1,2,3,8,9 are classified as stable fuels and #4-7 as unstable fuels.




Fig. 1 — Average Peroxide Number vs Stress Time — Fuel I




Fig. 2 — Average Peroxide Number vs Stress Time — Fuel 2




Fig. 3 — Average Peroxide Number vs Stress Time—Fuel 3




Fig. 4 — Average Peroxide Number vs Stress Time—Fuel 4




Fig. 5 — Average Peroxide Number vs Stress Time — Fuel 5




Fig. 6 — Average Peroxide Number vs Stress Time—Fuel 6




Fig. 7 -- Average Peroxide Number vs Stress Time -- Fuel 7




Fig. 8 -- Average Peroxide Number vs Stress Time -- Fuel 8




Fig. 9 — Average Peroxide Number vs Stress Time—Fuel 9




Fig 10 - Average Peroxide Number vs Stress Time - Fuel 4 - Expanded Scale




Fig. 11 — Average Peroxide Number vs Stress Time — Fuel 5 — Expanded Scale




Fig. 12 — Average Peroxide Number vs. Time—Fuel 6—Expanded Scale




Fig. 13 — Average Peroxide Number vs Stress Time — Fuel 7 — Expanded Scale




Fig. 14 -- Average Peroxide Number vs Siress Time--Fuel 9--Expanded Scale

END

8-87

DTIC